

FIG. 2

3/17

121




FIG. 3




FIG. 4

5/17

400




FIG. 5




FIG. 6

FOST 50" T6486860




FIG. 7




FIG. 8

9/17

500




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14

SHIFT



FIG. 16

QUICK TIPS

VOICE

VISUAL


1020

MOVE MOUSE OR
PRESS TO SELECT

SEAT CONTROLS
[DRIVER] 1005

PASSENGER 2 3 4

1007




SLIDE OR TOUCH TO ADJUST
ARM REST ADJUSTMENTS
SEAT HEATER ON OFF
SMART SEATS
CUSHION ADJUSTMENT
BACK SUPPORT ADJUSTMENT
AUTO TEMPERATURE CONTROL
MESSAGE ON OFF

DRIVER PASSENGER 1 2 3 4
SMART CLIMATE
AUTO CLIMATE
SET CLIMATE

CLIMATE CONTROL SYSTEM

1021 FRONT VENTS 1023



FAN CONTROLS
VENT CONTROLS
MANUAL AIR VOLUME
WINDSHIELD DEFROST
REAR DEFROST
MIRROR DEFROST
SMART ALL AUTO DEFROST
TEMPERATURE SET _____
AIR RECIRCULATION
ACTIVE FILTER SYSTEM
CONTAMINATION ALERT

MORE INFORMATION

SAVE PREFERENCES

WARNING MESSAGES

RESTORE SETTINGS




FIG. 17

09838491.051501

SELECTIONS FROM
MENU OR SCREEN

QUICK TIP: PRESS
ANIMATION TO HEAR AND
SEE DEMO

ANIMATION

VOICE

FIG. 18

SEE DEMO

MORE INFORMATION

MORE INFORMATION

USER ICON

AUDIO SYSTEM RADIO CASSETTE CD VIDEO TV WEATHER BAND

RADIO STATIONS: XX LOS ANGELES, XX SANTA ANA STATIONS
X IRVINE
SAVE AREA SETTINGS YES NO

SELECTION BEING PLAYED:
XX SONG, XX ALBUM 1245

OTHER
1247 1249

YOU ARE
LISTENING
TO:
AM107.8

1271
FM102.9 AM103.5

1273
FM100.7

1275
FM79.00

8 TALK/NEWS: FM89.9 FM91.2 AM98.6 AM10.70

5 ROCK: FM89.3 FM98.1

AM990 FM102.7 FM107.90

2 CLASSIC: FM91.4 FM96.4

SET FOR: (DRIVER) PASSENGER 1 2 3 4 5

ON OFF VOLUME CONTROL BASS TREBLE

FADER CONTROLS FRONT LEFT RIGHT BACK LEFT RIGHT

MOVE SPEAKERS FOR
DESIRED SOUND
EFFECTS
PRESSEFFECT THEN
SPEAKER
ROCK
SURROUND
MOVIE
ETC.

1251 1255 1257

YOU ARE HERE

QUICK TIP: SCROLL FOR
XX MORE STATIONS
USE MOUSE CONTROLS
OR PRESS TO SELECT

QUICK TIP: ANTENNA
IS ACTIVATED BY
RADIO AND TELEPHONE,
BOTH MUST BE
SWITCHED OFF TO
LOWER ANTENNA

STEREO
DOLBY
DIGITAL
ENCODED

SMART AUDIO
AUTO RADIO

RESTORE SETTINGS
MORE INFORMATION
SAVE PREFERENCES

1207

1205